


FTP 3/4

MODEL 34000

SEAL PUSHING

FEED WHEEL TENSIONER



PARTS LIST

KEY NO.	PART NO.	PART NAME	QTY.	KEY NO.	PART NO.	PART NAME	QTY.
1	34001	BASE	1	8	34008	SMOOTH PLUG	1
2	34002	NOSE PIECE	1	9	34009	BALL GRIP	1
3	34003	HAND GRIP	1	10	34010	RATCHET WHEEL	1
4	34004	HANDLE	1	11	34011	FEED WHEEL	1
5	34005	DRIVE PAWL	1	12	35012	FEED WHEEL KEY (1/8 x 1/8 x 3/4)	1
6	34006	DRIVE PAWL PIN (1/4 x 1 Roll Pin)	1	13	34013	FEED WHEEL SHAFT	1
7	34007	PAWL SPRING	2	14	34014	SCREW (1/4 x 20 x 3/8 HH)	2
				15	34015	WASHER (1/4 x 1)	2
				16	34016	ROCKER	1
				17	34017	ROCKER PIN	1
				18	34018	ROCKER SPRING	1
				19	34019	CHECK PAWL	1
				20	34020	CHECK PAWL PIN (1/4 x 2 Roll Pin)	1
				23	34023	NOSE PIECE SCREW	2
				24	34024	ROCKER ADJ. SCREW (10/32 x 5/8)	1
				25	34025	LOCK SCREW (8/32 x 1/4)	1

